

## Commandes

### Bouton du Centre


- Maintenir la touche enfoncée pour allumer
- Appuyer à nouveau pour changer le son
- Maintenir la touche enfoncée pour éteindre

Pour augmenter le volume

Pour baisser le volume

Indicateur de Batterie

- Rouge - Batterie faible
- Ambre - En cours de chargement
- Vert - Pleine charge



## Sons

Bruit Blanc

Océan

Pluie

Eau

Vent

Séchoir

Ventilateur

Berceuse

Battement de Cœur

Faire taire

Let's Go

## Controls

### Center Button


- Press and hold to turn on
- Press again to change the sound
- Press and hold to turn off

Volume up

Volume down

Battery Indicator

- Red - Low battery
- Amber - Charging
- Green - Fully charged



## Sounds

White Noise

Ocean

Rain

Water

Wind

Dryer

Fan

Rock-a-bye

Heartbeat

Hush

## Learn More

Pour en Savoir Plus

[hatch.co/rest-go-quick-start-guide](https://hatch.co/rest-go-quick-start-guide)



### IMPORTANT SAFETY INFORMATION :

Rest Go is intended to be used as a soothing on-the-go sound machine. Parents assume all responsibility for selecting volume and sound settings that are appropriate for their child. Never place against baby's ears or in a crib or bed. Always check with child's pediatrician prior to using any sound machine. Not a toy and not for teething. Do not leave the device charging next to your child. Never use in or near water, or if plastic housing is damaged or hot. Never disassemble. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### INFORMATIONS IMPORTANTES SUR LA SÉCURITÉ :

Rest Go est destiné à être utilisé comme une machine sonore apaisante lors de vos déplacements. Les parents sont entièrement responsables du choix du volume et des réglages sonores qui conviennent à leur enfant. Ne placez jamais l'appareil contre les oreilles du bébé, ou dans un berceau ou lit. Consultez toujours votre pédiatre avant d'utiliser n'importe quelle machine à sons. Il ne s'agit pas d'un jouet ni d'un appareil de dentition. Ne laissez pas l'appareil en charge à côté de votre enfant. N'utilisez jamais l'appareil dans ou près de l'eau, ou si le boîtier en plastique est endommagé ou chaud. Ne démontez jamais l'appareil.

© 2023 HATCH COMPANY, INC.